MD Series User Reference Guide

Joystick Control Unit (JCU)

Power Button
- Press to dim
- Press and hold for power menu

Menu Button
- Press to enable menu
- Press to exit menu

Scene Button
- Toggles through image contrast settings

JCU Puck
- Press and hold to zoom in
- Pull out to zoom out
- On-screen menus: move up/down by twisting or moving fore or aft
- Press to select (click)




LCD Display
- Displays JCU menu
- Use puck to move

User Button
- Toggles through color palettes

Home Button
- No effect (used with other cameras)


Color Button
- Toggles through color palettes

Web Interface Toolbar Buttons



MD Series User Reference Guide

Video Screen Icons



432-0010-00-11 v100 Mar 2013